




## BEGIN USING YOUR CRUMBEE



1. Flip the switch to the left to wake up Crumbee. Turn the switch to the right to put Crumbee back to sleep.




Battery



2. Feed Crumbee two AA batteries (included).

## KEEP CRUMBEE CLEAN



1. Make sure Crumbee is turned off and pull Crumbee apart. (Don't worry, Crumbee can't feel a thing!)




2. Empty Crumbee's tummy by pulling apart the bottom piece and throwing away any scraps.



3. To reassemble Crumbee, snap the bottom and top back together.

Make sure Crumbee is tightly reset.

## MAINTAIN CRUMBEE





Filter

To keep Crumbee squeaky clean, remove the filter and clean it with a brush. To avoid any damage to Crumbee, do not let water enter into the machine.

## DISPOSAL OF CRUMBEE

Crumbee helped keep your desk clean, so please help keep the Earth clean by disposing of Crumbee's batteries responsibly.

## CRUMBEE ANATOMY



1	Top Cover	5	Bottom Cover
2	Battery Case Button	6	Brush
3	ON/ OFF	7	Propeller
4	Middle Shell	8	Filter

## CAUTION

1. To avoid injuries, do not put your fingers into the center of Crumbee.
2. You wouldn't like to be disassembled and neither does Crumbee! Don't disassemble or modify the machine, please.
3. Crumbee is great for cleaning up small messes like keyboard dust, and paper scraps. Avoid using Crumbee to clean up liquids and larger debris.

*Origaudio*<sup>™</sup>

[www.origaudiopromo.com](http://www.origaudiopromo.com)



## PRODUCT DETAILS

Product Name	Crumbee
Main Material	ABS
Battery	2*AA
Battery Voltage	3V
AA Battery Life	100 hours with typical use

Crumbee includes batteries and a small brush.

This product contains small parts. Not intended for children under the age of 3.

© 2020 Forty Four Group, LLC., d/b/a Origaudio ·  
Printed in California · Made in China

## CRUMBEE INSTRUCTION MANUAL

### DESKTOP VACUUM CLEANER

